


2. Air Filters And Cylinders



No.	Description	Ref. Part No.	QTY
1	Head, LP	1614030202	1
2	Rubber ring	1404178000	2
3	Copper washer	0653104100	1
4	Plug	0686370100	1
5	Nut	0268310800	8
6	Spring washer	0333213800	8
7	Cord 3 x 796	1619033300	1
8	Stud	1404124800	8
-	Liner Set LP & HP (9&13)	VT LINER	1
9	Liner LP	1614130002	1
10	O-ring	0663786800	1
11	Head, HP	1614030302	1
12	Cord 3 x 512	1619033400	1
13	Liner HP	1614030102	1
14	O-ring	0663785400	2
15	Plate, mounting	1613023700	2
16	Screw	0144344700	4
17	Spring washer	0333214300	4
18	Nut, wing	0296130600	1
19	Washer	0300014800	1
20	Cover	1615015802	1
21	Nylon tube	1615017800	1
22	Stem	1613018700	1
23	Element, filter	1619161300	1
24	Housing, air filter	1613017004	1
25	Spring washer	0333213800	1
26	Screw	0144336000	2
27	Copper washer	0653106200	1
28	Eye, lifting	1613043002	1
29	Plastic tube (drain)	1613121702	1
30	Clamp	0346210800	1
31	Shim	1613120600	1
32	Warning device	1619122100	1