

**14 - ASSEMBLY VALVE DISCHARGE - IR -  
MODEL - 4 x 5 ESV NL**

DISCHARGE VALVE




FIG-7

**14 - ASSEMBLY VALVE DISCHARGE - IR -  
MODEL - 4 x 5 ESV NL**

Sr.No	Description	Ref Part Nos	Qty
-	. ASSEMBLY VALVE DISCH A28 NL TYPE.	70265244	-
-	. . VALVE DISCHARGE A28CS2EWSA 400/600	30551253	-
-	. . . SEAT VALVE (IN/DIS) PROC	37020492	1
-	. . . PLATE SEAT A28	17278409	1
-	. . . HOLDER GUIDE PROC	30258479IM	2
-	. . . SCREW MACHINE ESV	37057577	4
-	. . . STOP PLATE(IN/DIS) DISCH	37074564	1
-	. . . CHANNEL & SPRING SET	17288085	1
-	. . . SCREW MACHINE	95110573	2
-	. . GASKET VALVE SEAT	30549885	1
-	. . CRAB VALVE IS 210 GR 20 CI	30533566	1
-	. . SCREW SS M/C NO.10X1	95111258	2
-	. . WASHER SPRING 3/16	95037131	2