


17. ASSEMBLY HEAD OUTER - MODEL 7 x 5 LUB



All manufacturer's names, numbers, photos, product description and/or part numbers are used for reference purposes only & it is not implied that any part listed is the product of these manufacturers. Since Approvement are made from time to time, the illustration and specifications are subject to change without notice.

17. ASSEMBLY HEAD OUTER - MODEL 7 x 5 LUB

| No. | Description | Ref Part No. | QTY |
|-----|--------------------------------|--------------|-----|
| – | Assembly Head Outer | 70402706 | – |
| 1 | – Head Outer | 37085958 | 1 |
| 2 | – Gasket Head Outer | 39542121 | 1 |
| 3 | – Cover Inlet Valve | 37087822 | 1 |
| 4 | – Gasket Cover Valve | 39486055 | 1 |
| 5 | – Screw Cap Hex Head 3/8" Dia. | 95103743 | 5 |
| 6 | – Cover Discharge Valve | 37087830 | 1 |
| 7 | – Gasket Cover Discharge Valve | 39550017 | 1 |
| 8 | – Screw Cap Hex 1/2" Dia. | 95104147 | 7 |
| 9 | – Screw Cap Outer Head | 37795200 | 8 |