


4. HOUSING MAIN BEARING & OIL PUMP - MODEL 8 x 5 LUB



All manufacturer's names, numbers, photos, product description and/or part numbers are used for reference purposes only & it is not implied that any part listed is the product of these manufacturers. Since Approvement are made from time to time, the illustration and specifications are subject to change without notice.

4. HOUSING MAIN BEARING & OIL PUMP - MODEL 8 x 5 LUB

No.	Description	Ref Part No.	QTY
1	Housing Main Bearing	37073624	1
2	Plate Rotation	39516646	1
3	Screw Machine 0.114" X 0.25"	39175070	2
4	Screw Cap Hex Head 5/8" X 3/4"	95104477	2
5	"O" Ring 10-1/2" X 11" X 1/4"	95098067	1
6	Elbow Male 5/8"	94425162	1
7	Breather Elbow	39314323	1
8	Filter Oil	30472161	1
9	Adapter Oil Filter	30179220	1
10	Cap Breather	30557888	1
11	Bush Main Bearing Housing 5"	30557557	2
12	Plug Co. Sunk 3/8"	95101705	2