


14.1 OPERATOR UL-91



14.1 OPERATOR UL-91

No.	Description	Ref Part No.	QTY
9-1	OPERATOR UL-91	39245519	1
9-1	COVER LOW PISTON HOUSING	39227723	1
9-2	HOUSING PISTON	39227731	1
9-3	GASKET	39227749	1
9-4	COVER UP PISTON HOUSING	39227753	1
9-5	CAPSCREW	95068227	2
9-6	PISTON 3.25	39227764	1
9-7	ORING	95000477	1
9-8	PUSHROD	39227772	1
9-9	ORING	95045092	1
9-10	ORING	95022810	1
9-11	PISTON STOP	39227798	1
9-12	SPRING	39227806	1
9-13	SPRING (not used in this assembly)	N/A	N/A
9-14	ELBOW 90 DEG ST	95408258	1
9-15	PLUG PIPE	95033353	1
9-16	CAPSCREW	95088219	4