



No.	Description	Ref Part No.	QTY
_	VALVE DISCHARGE	37022829	_
1	- STOP PLATE	31206303	1
2	– HOLDER GUIDE	31535867IM	2
3	- GUIDE VALVE	37041324	6
4	– SEAT PLATE	30661995IM	1
5	- SCREW MACHINE	95110763	2
6	- CHANNEL & SPRING SET	30635064IM	1
7	- SCREW GUIDE	31208549IM	4
_	– HOLDER GUIDE CENTRE	37025483IM	1

All manufacturer's names,numbers,photos,product description and/or part numbers are used for reference purposes only & it is not implied that any part listed is the product of these manufacturers. Since Approvement are made from time to time, the illustration and specifications are subject to change without notice.